



Installation & Operation Manual

List

1 Overview

- 1.1 Product Overview
- 1.2 Applicable Personnel

2 Safety Precautions

- 2.1 Safety Overview
- 2.2 Symbol
- 2.3 Meaning of Symbol

3 Product Introduction

- 3.1 Appearance
- 3.2 Dimensions
- 3.3 Nameplate
- 3.4 Working Principle
- 3.5 Inverter Storage
- 3.6 Grid Types
- 3.7 AFCI Detection Function
- 3.8 Anti-PID Function

4 Unpacking

5 Installation

- 5.1 Basic Installation Requirements
- 5.2 Installation Environment Requirements
- 5.3 Moving Requirements
- 5.4 Wall Mounted Installation
- 5.5 Installing the Inverter

6 Connecting Cables

- 6.1 Connection on AC side
- 6.2 Connection on DC side
- 6.3 Connection of Communication Cables
- 6.4 Inverter demand response modes (DRMS)
- 6.5 Connecting the Ground Cables

7 System Commissioning

- 7.1 Inverter Commissioning
- 7.2 Modes
- 7.3 LED display

8 Monitoring

- 8.1 Remote Data Monitoring
- 8.2 Local Data Monitoring

9 Maintenance

- 9.1 Routine Maintenance
- 9.2 Trouble Shooting

10 Product Specification

11 Decommissioning

12 Quality Assurance

13 Contact Us

1 Overview

1.1 Product Overview

This manual is aimed at providing sufficient information and installing instruction for consumers buying Shenzhen Growatt New Energy Co.,Ltd (short as Growatt) MAX-X2 Series solar inverters. Please read this manual carefully before using the MAX-X2 series inverters and store the manual in a reachable place for an authorized technician. No further notice if there is any change in this manual.

1.2 Applicable Personnel

Only qualified electrical technicians are allowed to install MAX-X2 series inverter. With reading through this manual and following all the precautions, qualified electrical technician can properly install MAX-X2 serial inverter, finish trouble shooting and communication settings.

If there is any problem during the installation, the installer can either log on www.ginverter.com and leave a message or call consumer service hotline +86-755-2951 5888.

2 Safety Precautions

2.1 Safety Overview

- 1>Read this manual carefully before installation. If the equipment is damaged due to non-compliance with the manual or exceeds the installation/usage scope specified in international standards, Growatt New Energy reserves the right to void the warranty.
- 2>All the operations and connections must be done by trained qualified electrical technician.
- 3>During installation except for terminals, do not touch any inside part of the inverter.
- 4>All the electrical connections must meet local country's safety regulations.
- 5>If you need maintenance for this inverter, please contact our local authorized installing and maintenance technician.
- 6>You must get the local power supplier's permit before connecting this inverter to the grid.

Handle Process:

 WARNING	• The inverter is heavy,please treat with care while handling,in case of crushing injury.
--	---

Installation:

 NOTICE	• Before installation,please read through this manual,any damage cause by improper installation,Growatt reserve the right to disclaim any warranty.
 DANGER	• Ensure that the inverter is not connected to a power supply and is not power on before installation.

 WARNING	• Please follow this installation manual as installation condition environment,space and so on. • Please install the inverter in a dry and ventilated environment,otherwise may affect the performance of the inverter. • Please follow the installation procedures in this manual.
---	---

Electrical Connections:

 DANGER	• Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk. • Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations. • High voltage may cause electric shocks and serious injury please do not touch the inverter. • Please do not store inverter in area with flammable and explosive material.
 WARNING	• Each inverter must install one AC breaker; AC breaker is forbidden to share with other inverters. • It is forbidden to add load between inverter and breaker. • If the cable is thick, after tightening the cable do not shake it and ensure the cable is well-connected and then start the inverter.Loose connection may cause overheat. • Before connecting between PV panels and inverter please ensure the positive and negative poles are correct connected.

Maintenance and replacement:

 DANGER	• Must be installed by trained and authorized electrical technician and accurately follow this manual. • Please disconnect the DC and AC switch for at least five minutes, all the operations should be carried after power disconnection. • If there is PV isolation low alarm, the inverter case may be ungrounded, please do not touch the inverter case. • High voltage of inverter may result in electric shock.
 WARNING	• For better cooling purpose, please regularly clean the fans. • Do not use air pump to clean the fans, cause it may damage the fans.

Other:

	• After you receiving the inverter please check the packing materials for damage,if there is any damage please contact your supplier.
 WARNING	• The Max PV input voltage should not exceed 1100V. • For the disposed inverter,the consumer should dispose it according to local disposal rules for electrical equipment waste.

2.2 Symbol Conventions

Symbol	Description
 DANGER	Indicates an imminently hazardous situation which,if not avoided, will result in serious injury or death.
 WARNING	Indicates potentially hazardous situation which,if not avoided,will result in serious injury or death.
 CAUTION	Indicates potentially hazardous situation which,if not avoided,will result in minor or moderate injury.
 NOTICE	Indicates certain hazardous situation which,if not avoided,will result in property damage.
	Reminds operator to read installation manual before operating or installing inverter.

2.3 Lable Description

Symbol	Name	Meaning
	High Voltage Electric Shock	Inverter operating with high voltage, any operation regarding inverter need to be done by trained and authorized electrical technician.
	Burn Warning	Do not touch a running inverter cause it generates high temperature on the case.
	Protective Grounding	Connect inverter to grounding bar.
	Delay discharge	Residual voltage exists after the inverter is powered off, it takes 5 minutes for the inverter to discharge to the safe voltage.
	Read the installation manual	Reminds operator to read installation manual before operating or installing inverter.
	DC	Means this terminal is for DC side.
	AC	Means this terminal is for AC side.
	CE Mark	The inverter complies with the requirements of the applicable CE guidelines.

3 Product Introduction

3.1 Appearance

Front view:




Fig 3.1

Bottom view(Termial):




Fig 3.2

Side view:




Fig 3.3

Mark	Description	Mark	Description
A	Front panel	H	COM interface
B	LED	I	Corner guard
C	PV terminal	J	Waterproof silicone pad
D	DC switch	K	Heat sink
E	Breathing valve	L	Ground screw hole
F	External fans	M	Junction Box
G	USB interface		

3.2 Basic Data

Model	Size(mm)			Weight (kg)
	Width	Height	Thickness	
MAX-X2 Series Inverter	970	640	345	84
MAX-X2 Series Inverter with package	1095	765	500	98

3.3 Nameplate

GROWATT PV Grid Inverter	
Model name	MAX 125KTL3-X2 LV
Max. PV voltage	1100 d.c.V
PV voltage range	180-1000 d.c.V
PV Isc	56.5 d.c.A*8
Max. input current	45 d.c.A*8
Max. output power	125 kW
Max. apparent power	137.5 kVA
Nominal output voltage	3W/N/PE 230/400 a.c.V
Max. output current	208.9 a.c.A
Nominal output frequency	50/60 Hz
Power factor range	0.8leading~0.8lagging
Safety level	Class I
Ingress protection	IP66
Operation ambient temperature	-30°C - +60°C
VDE0126-1-1 	
Made in China	

Note: Other models of MAX-X2 series share the same label design with MAX 125KTL3-X2 LV, only with different model name and parameters, detail parameter please refer to specification in Chapter 10.

3.4 Working Principle

- The MAX-X2 series inverter works as follows:
- 1>The PV panels gather solar to generate DC power to inverter.
 - 2>With input current detection circuit, it can monitor all the PV panels' working status and use MPPT to track the maximum power point.
 - 3>With inverter circuit change DC power to AC power, and feed power back to grid per grid requirement.
 - 4>With output isolation relay can isolate AC output and grid, if anything goes wrong on either inverter side or grid side, isolation relay can disconnect inverter immediately.

On-grid connection system diagram:




Fig 3.4

symbol	Description	symbol	Description
A	PV string	C	Electric meter
B	Inverter	D	Grid

3.5 Inverter Storage

- 1>Do not unpack the inverter and store it in a ventilation dry place .
- 2>Keep the storage temperature at -30 ℃- +60℃ and humidity at 0-95%.
- 3>A maximum of three inverters with package can be stacked.
- 4>If the inverter has been long-term stored, inspections and tests should be conducted by qualified personnel before it is put into use.

After being stored for a month or longer, the inverter's time and date could be wrong, you need set the time and date before using, for more details please refer to Chapter 7.1 inverter commissioning.

3.6 Grid Types

The MAX-X2 series, MAX100-133KTL3-X2 LV inverters connect to the grid like following drawing 3.5,MAX 125-150KTL3-X2 MV inverters connect to the grid like following drawing3.6.




Fig 3.5




Fig 3.6

3.7 AFCI Detection Function

AFCI (Arc Fault Circuit Interrupter) is a kind of circuit protection device, the main function is to prevent the fire caused by fault arc. The electrical insulation aging, breakage, loose connection, air breakdown caused by air humidity and so on, all of these may cause an electric spark, which is called arc.

The AFCI function of the MAX-X2 series inverter is optional, and the detection equipment is assembled inside the inverter. When an arc-drawing condition is detected on the PV input side, the arc current could be detected by the CT assembled on the PV input-side wire. Then the inverter will shut down. Meanwhile, the inverter will display the corresponding fault message and the buzzer will sound, which could help to avoid harm and economic loss to the user.

NOTE: AFCI function is optional.

3.8 Anti-PID Function

The full name of PID is Potential Induced Degradation. Since the PID effect, a large amount of charge could accumulate on the surface of the photovoltaic module, which makes the surface passivation of the module worse. Eventually, the fill factor, open-circuit voltage, and short-circuit current of the module are reduced, and the power of the photovoltaic module is attenuated.

The Anti-PID function uses the principle of reversible PID changes. MAX-X2 series inverters rectify AC voltage at night and boost it to generate a DC voltage. The DC voltage is connected to PV + and the ground respectively. When add a positive bias voltage to the module to make the PID effect reverse, the Anti-PID function could repair the photovoltaic modules at night and prolong the service life of photovoltaic modules.

NOTE: Anti-PID function is optional.

4 Unpacking

Checking before installation

- 1>Before unpacking the inverter, check the outer packing materials for damage.
- 2>After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

Package contents:




Fig 4.1

Mark	Descriptions	Number
A	Inverter	1
B	Wall mount	1
C	PV + terminal, PV- terminal	16/16
D	PV terminal metal core	16/16
E	Removal tool of PV terminals	1
F	Installation manual	1
G	Warranty card	1
H	Communication terminal	1
I	M10*90 Expansion screw	4
J	M6*28 stainless steel screw	2
K	AC wiring copper terminal (SC95-12)	4
L	Grounding terminal (RH50-8)	1
M	Data logger(Optional)	1

Installation 5

 CAUTION	• To prevent device damage and personal injury, keep balance when moving the inverter because it is heavy. • Do not place the inverter with its wiring and signal terminals at the bottom contacting with floor or any other object because the terminals are not designed to support the weight of inverter. • When placing inverter on the floor, put foam or paper under the inverter to protect its cover.
---	--

5.1 Basic Installation Requirements

- A. Ensure that the installation wall is solid enough to bear the inverter(Inverter weight please refer to installation manual Chapter3, 3.2).
- B. There must be enough installation space to fit the size of inverter.
- C. Do not install the inverter in flammable, explosive, or smoky environments, or on buildings made of heat-sensitive materials.
- D. This inverter is IP 66 protection, you can install it indoor or outdoor.
- E. To avoid inverter performance de-rate due to the over heat, please do not expose the inverter under direct sunlight.
- F. The installation humidity should be from 0-95%.
- G. The ambient temperature around the inverter should be between -30°C and $+60^{\circ}\text{C}$. In dusty environments (e.g., areas with smoke, dust, or excessive fibers), particles may accumulate on the inverter's vents or heat sinks, affecting heat dissipation and potentially causing damage. Avoid installing the inverter in dusty environments. If unavoidable, regularly clean the fans and heat sinks to ensure proper cooling.
- H. Inverter should be installed in a vertically or rear tilted surface, please refer to following drawings.




Fig 5.1

- I. To ensure the inverter can work smoothly and easy for personnel to operate, please notice there is sufficient space for inverter, refer to following drawing.




Fig 5.2

- J. Do not install the inverter in areas with strong vibrations, loud noise, strong electromagnetic interference, or near strong electromagnetic signals.
- K. Install the inverter out of children's reach.
- L.If the inverter is installed in a lush vegetation environment, modify the ground beneath it by laying cement or gravel (recommended area: at least 3m × 2.5m).
- M.If the inverter remains unused for over six months after installation, it may malfunction and require professional inspection before use. If installed in a sandy/dusty environment, add protective measures to the vents to prevent long-term dust accumulation and blockage. Remove these protections before use.

5.2 Installation Environment Requirements

A. Although the inverter's protection level is IP 66, to extent inverter lifespan you still need to avoid rain and snow, please refer to following drawings.



Fig 5.3

B. To reduce the de-rate performance of the inverter and extend inverter's life span, we strongly recommend you install an awning, for the distance between an awning and inverter, please refer to following drawing.




Fig 5.4

C. When you install multiple inverters on one surface, inverters should be installed as following drawing. (Choose one of the two options below).




Fig 5.5




Fig 5.6

D. Do not install inverter into an enclosed space like following drawing.




Fig 5.7

5.3 Moving Requirements



WARNING

- The inverter is heavy, please move it with care and keep balance to avoid personnel injury.
- Do not place the inverter with its wiring and signal terminals at the bottom contacting with floor or any other object because the terminals are not designed to support the weight of inverter.

1>As shown in Fig 5.8, 4-6 persons are required to lift the inverter out of the package and move it to the installation position.

2>When you are moving the inverter, please keep the balance.

Notice: There will be front and bottom mark on the package.




Fig 5.8

5.4 Wall Mount Bracket Installation

Before install the inverter you need install the wall mount bracket so that the inverter can be firmly installed on the wall.

Wall mount plan:




Fig 5.9

1>Use the wall mount plate as a template drill holes on the wall and put in expansion bolts.




Fig 5.10

Notice:Expansion bolt should be installed on solid walls with at least 100mm thickness.

2>Follow the following drawing put the bolt to install the wall mount plate on the wall.




Fig 5.11

Notice: Do not install inverter unless you have confirmed the wall mount plate has been firmly installed on the wall.

5.5 Installing The Inverter

After the wall mount bracket has been firmly installed on the wall , put the inverter on that plate.

1>Use the rope(must meet the weight requirement of the inverter) Pass through two supporting feet before lifting, as shown in the diagram below.

2>Before hanging the inverter on the wall mount bracket use screws to fix the inverter and please keep the inverter balance.

3>Check the inverter if it is firm enough and lock all the screws.




Fig 5.12




Fig 5.13




Fig 5.14

Connecting Cable 6

Decisive Voltage Class (DVC) indicated for ports

Port Name	Class
AC	C
DC	C
DRMS	A
RS485&USB	A

6.1 Connection on AC side

 DANGER	• Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk. • Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations. • High voltage may cause electric shocks and serious injury please do not touch the inverter. • Please do not store inverter in area with flammable and explosive material.
 WARNING	• Each inverter must install one AC breaker, AC breaker is forbidden to share with other inverters. • It is forbidden to add load between inverter and breaker.

Preparation before connection:

1>Disconnect inverter DC switch and AC breaker or switch.

2>When you lock the AC cable's screw, the torque force should be 35N·m (350kgf·cm).
When you lock the cover screw, the torque force should be 2.5-3.0N·m (25-30kgf·cm).

3>Measure the grid voltage and frequency, please refer to chapter 10.

AC breaker specification:

Inverter model	Breaker model
MAX 100KTL3-X2 LV	200A/400Vac
MAX 110KTL3-X2 LV	250A/400Vac
MAX 120KTL3-X2 LV	250A/400Vac
MAX 125KTL3-X2 LV	250A/400Vac
MAX 133KTL3-X2 LV	315A/400Vac
MAX 125KTL3-X2 MV	200A/500Vac
MAX 136KTL3-X2 MV	250A/500Vac
MAX 150KTL3-X2 MV	250A/500Vac

Cable specification:

Inverter Model	Copper wire crossectional area(mm²)	Copper wire recommendation (mm²)	Aluminum wire recommendation (mm²)
MAX 100KTL3-X2 LV	70-240	70	95
MAX 110KTL3-X2 LV			
MAX 120KTL3-X2 LV			
MAX 125KTL3-X2 LV			
MAX 133KTL3-X2 LV			
MAX 125KTL3-X2 MV			
MAX 136KTL3-X2 MV			
MAX 150KTL3-X2 MV			

Notice:The cable must be unbroken.
When using aluminum alloy cables, please use copper-aluminum transition terminals.

AC side connection steps:



WARNING

- If the cable is thick, after tightening the cable do not shake it and ensure the cable is well-connected and then start the inverter. Loose connection may cause overheat.

1> Following drawing shows inverter's AC terminal, R, S, T are three live lines, N is Neutral line.




Fig 6.1

2> Determine the stripping length (approximately 30mm) according to the specifications of the crimping terminal. Use crimping tools to crimp the wires and terminals, then connect the cables to the corresponding channels through the waterproof interface, and tighten the screws.




Fig 6.2

NOTE: Use a torque wrench to tighten the screws/nuts with reference to the torque ranges provided above.

Diagram of how to install a terminal:




Fig 6.3

NOTE: Use a torque wrench to tighten the screws/nuts with reference to the torque ranges provided above.

 WARNING	- OT/DT terminals require additional tin-plating surface treatment to enhance their corrosion resistance. - When using copper-aluminum bimetallic lugs, they must comply with the requirements of IEC61238-1. - It is strictly prohibited for copper terminals to come into direct contact with aluminum alloy cables, as this will cause electrochemical corrosion, affecting the reliability of the cable connection. - When using copper-aluminum bimetallic lugs, it is strictly prohibited for the copper terminal block to come into direct contact with the aluminum part of the copper-aluminum bimetallic lug, as this will cause electrochemical corrosion, affecting the reliability of the cable connection.
---	---

For the requirements regarding OT/DT terminals, please refer to Figure 6.4 below for specific content.




Fig 6.4

For the correspondence between the diameter of single-core and multi-core wires and the number of removed sealing rings, as well as the wiring method for single-core wires, Please refer to the following for the specific operation .

Reference Table: Single-Core Wire Diameter vs. Number of Removed Sealing Rings




Fig 6.5

Reference Table: Multi-Core Wire Diameter vs. Number of Removed Sealing Rings




Fig 6.6

The illustration of single-core wire wiring in the complete unit is shown in Figure 6.7 below, and the illustration of multi-core wire wiring in the complete unit is shown in Figure 6.8 below.




Fig 6.7




Fig 6.8

Please clear any foreign objects from the terminal box, close the terminal box cover, confirm that the cable entry holes at the bottom of the terminal box are sealed, and finally tighten the screws as shown in Figure 6.9.




Fig 6.9

3>Upon completion of the AC wiring, remember to seal the water-proof silicone mat with the fireproof mud in order to ensure good waterproof performance.



WARNING

- The device damage caused by failure to seal the output terminal gaps as instructed is beyond the scope of warranty and Growatt New Energy shall not be liable for the damage.




Fig 6.10

6.2 Connection On DC Side

 DANGER	• Before electrical connection, please ensure the inverter DC switch is at "OFF" also disconnect AC switch, otherwise the high voltage from inverter may cause life risk. • Only trained authorized electrical technician can do the electric connection also please follow the connection procedures in this manual along with local country's regulations. • High voltage may cause electric shocks and serious injury please do not touch the inverter. • Do not place flammable or explosive materials around the inverter.
--	--

Notice: The sunlight will generate voltage on the solar panels, after serial connection, the high voltage may injure personnel, so before connect DC input cable you need cover solar panels with light-tight materials and make sure the inverter DC switch is at "OFF" status, otherwise high voltage may injure personnel.

 DANGER	• The DC switch will automatically trip when an internal inverter fault occurs (indicated by a steady red alarm or fault LED light, and the DC SWITCH will trip automatically). After the switch trips, please contact the customer service center. Do not manually close the DC switch. • The DC switch will automatically trip and enter the "OFF" state when the inverter encounters alarms such as "String Reverse Connection" or "String Reverse Current". In this case, do not reset the DC switch immediately. First, check the fault type via monitoring data, etc. Only after the fault is resolved should the reset/close operation be performed. Please refer to the following for the specific operation 9.3.
--	--



WARNING

• Please ensure that the following conditions are met, as failure to do so may damage the inverter or pose a fire hazard. In such cases, the company shall not be liable for any consequences.

1>Each string's maximum open circuit voltage cannot exceed 1100Vdc, otherwise it could lead to fire or damage the inverter. If the inverter was damaged by higher maximum open circuit voltage (higher than 1100Vdc), product warranty will be forfeited and Growatt will not take any responsibility.

2>Each string solar panels should be same brand and same model. The inverter shall be used with IEC 61730 Class A rating PV module.

3>Under any circumstance, the maximum short circuit current should not exceed 40A.

4>The total panels power should not exceed 1.5 times of inverter input power.

5>To optimize system settings, recommend two strings with same amount solar panels.

6>Please use the positive and negative metal contacts and the DC connectors delivered with the inverter package. Using other incompatible models may result in severe consequences, which will void the warranty.

7>When assembling the DC connectors, pay attention to the correct polarity and label the positive and negative cables.

8>Crimp the PV metal contact with a dedicated crimper. Using an inappropriate crimping tool may lead to severe consequences, and any device damage caused by this is not covered by the warranty.

9>Cables with high rigidity are not recommended for the DC input as bending of cables may lead to poor contact of terminals.

10>According to the specification of the crimping terminal, determine the stripping length, crimp the wire and terminal with the crimping pliers, and connect them to the corresponding connector housings separately, and hear the click sound to ensure the connection is good. After snapping the positive and negative connectors into place, pull the cables slightly to ensure that they are securely in place.

11>Connectors need to be fit with male and female terminals, before connecting panels with inverter please make sure the positive pole and negative pole, namely the solar panels' positive pole connect to "+" negative pole connect to "-".




Fig 6.5




Fig 6.6

12>For the unused PV terminls on the inverter, please cover them with blue dustproof caps.

13>When wiring the DC input cables at the installation site, leave at least 50 mm of them slack. The axial tension on the PV connector should not exceed 80N and do not apply radial stress or torque on the PV connectors.

14> Connect the positive and negative poles to inverter terminals, different inverter's maximum single string input current please refer to following table.

Inverter model	Max. single string input current
MAX-X2 serial inverter	22.5A*2

15> Cable specifications:

Inverter model	Cross-sectional area(mm ²)	Recommendation (mm ²)	Cable outer diameter(mm)
MAX-X2 serial inverter	4-6	4	4.5-7.8

Notice:

1.Under any circumstance, the total current of all strings cannot exceed the inverter's maximum current.

2.Do not touch any working solar panels.

3.Make sure the cable is unbroken.

6.3 Connection Of Communication Cables

6.3.1 RS485 port

Rs485 can carry out single-machine communication or multi-machine (32pcs) long-distance (500 meters) high-speed (baud rate 38400) communication. It is recommended to use twisted-pair shielded wire for RS485 communication line. For single-machine communication, the communication line can be connected to pin 3/4, and its shielding layer can be connected to pin 1. When multiple machines are connected in parallel, two RS485-1 ports can be connected at the same time. When used, the shielding layer can be connected to pin 1/2. In Figure 6.7, RS485 has two terminal types, terminal type 1 and terminal type 2.




Fig 6.7

Port	PIN	Description	Port	PIN	Description
Shield ground	½	485-1 / 485-2 PE shield	DRMS	9	DRM1/5
RS485-1 IN	3	485-1 A1		10	DRM2/6
	4	485-1 B1		11	DRM3/7
RS485-1 OUT	5	485-1 A1		12	DRM4/8
	6	485-1 B1		13	REF/GEN
RS485-2	7	485-2 A1		14	DRM0/COM
	8	485-2 B1	RS485-1 Matching resistance	15/16	485-1 Matching resistance

Notice:

1. When multiple inverters communicate in parallel, the last machine needs to add matching resistance. The method is to use a wire to connect the pin 15/16 together.
2. Terminal type 1 and terminal type 2 randomly match the whole machine shipment. The performance of the two terminals is consistent, only different in appearance. The client needs to match the corresponding shape terminal to use.

In MAX-X2 series inverters, RS485 interface is standard. The connection steps of RS485 communication line are as follows:

- 1) Unscrew the waterproof cover of the COM interface and remove it.
- 2) Connect the RS485 communication line to the port of 485-1.
- 3) RS485-1 can be used for multi-machine parallel communication and multi-machine countercurrent prevention, while RS485-2 can be used for multi-machine parallel communication and single-machine countercurrent prevention.
- 4) The inverter is connected hand in hand through the RS485 communication line, and the end of the communication line 485_A/B is connected to the monitoring equipment to realize multi-machine remote monitoring.

Note: When locking the RS485 cable screw, the torque is 0.4-0.6N·m (4-6kgf·cm).




Fig 6.8

6.3.2 USB port

The MAX-X2 series inverters are equipped with a USB interface as standard, which can be connected to a USB to WIFI module, Shine GPRS-X2, Shine WIFI-X, Shine 4G-X, Shine Link-X and other optional monitoring modules to realize remote Monitoring function. In addition, you can also quickly upgrade the inverter software through the U disk.

Steps to install the monitoring module:

- 1> Loosen the waterproof cover of the USB interface and remove it.
- 2> As shown in Figure 6.9A, insert the Shine GPRS-X2 module into the USB interface, and the LED of the Shine GPRS-X2 module will be on.
- 3> As shown in Figure 6.9B, make sure that the Δ is facing upwards, insert the monitoring module into the USB interface, and tighten the lock.

Note: If you use a USB to WIFI module, when the operator leaves, please take the module and the data cable away, and tighten the waterproof cover to prevent water from entering the interface.





Fig 6.9A

Install



Remove




Fig 6.9B

6.4 Inverter demand response modes (DRMS)

This series inverter has the function of demand response modes, We use 16-Pin socket as inverter DRMS connection.

 Information	DRMS application description ➤ Applicable to Commission Regulation (EU) 2016/631. ➤ DRM0, DRM5, DRM6, DRM7, DRM8 are available.
 CAUTION	Damage to the inverter due to moisture and dust penetration ➤ Make sure the cable gland has been tightened firmly. ➤ If the cable gland are not mounted properly, the inverter can be destroyed due to moisture and dust penetration. All the warranty claim will be invalid.
 WARNING	Excessive voltage can damage the inverter! External voltage of DRM PORT don't over +5V.

6.4.1 Using the Power Control Interface for EU




Fig 6.10 Inverter – RRCR Connection

6.4.1.1 The following table describes the connector pin assignment and function:

DRM Socket Pin NO.	Description	Connect to RRCR
9	Relay contact 1 input	K1 – Relay 1 output
10	Relay contact 2 input	K2 – Relay 2 output
11	Relay contact 3 input	K3 – Relay 3 output
12	Relay contact 4 input	K4 – Relay 4 output
13	GND	Relays common node
14	Not connected	Not connected

6.4.1.2 The inverter is preconfigured to the following RRCR power levels:

DRM Socket Pin 9	DRM Socket Pin 10	DRM Socket Pin 11	DRM Socket Pin 12	Active power	Cos(φ)
Short circuit with Pin 13				0%	1
	Short circuit with Pin 13			30%	1
		Short circuit with Pin 13		60%	1
			Short circuit with Pin 13	100%	1

Active power control and reactive power control are enabled separately.

6.5 Connecting The Ground Cables

In this solar system all the unloaded metal components and cases should be connected to the ground.

Single inverter need grounding over a PE point, multiple inverters need connect all the inverter PE cable and solar panels shelves to the same grounding point to achieve equipotential.

The grounding steps as following:

Take out the ground screw at the inverter bottom, connect the ground cables as following figure.

Notice: 1. The machine is safely separated from the lightning protection and the distance is as far as possible.

2. Do not expose Grounding terminal in the air and precaution for the rain.

3. When you lock the case ground screw, the torque force should be 6-8N·m (60-80kgf·cm).




Fig 6.11

According to the relevant provisions of IEC 61643-32 "Connecting to photovoltaic devices surge protectors - selection and use of guidelines", whether for household or outdoor photovoltaic power plants, it is necessary to ensure the implementation of lightning protection measures for photovoltaic systems:

 WARNING	The lightning protection measures for photovoltaic systems shall be carried out in accordance with the corresponding national standards and IEC standards. Otherwise, photovoltaic devices such as components, inverters and power distribution facilities may be damaged by lightning. In this case, the company does not carry out warranty and assumes any responsibility.
---	---




Fig 6.12

1) It is generally recommended to install lightning protection devices (such as lightning rods / lightning protection belts and down conductors) to prevent lightning from hitting the PV array.

2) Lightning protection devices and down-conductors and related equipment in photovoltaic systems (including photovoltaic panels, inverters, cables, power distribution equipment) should maintain a safe separation distance S .

Suggested value of S : According to the general 5 storey height (about 15m) building roof, S takes 2.5m enough, this distance can be simplified according to the inverse relationship of the floor height.

A. When the safety distance S is satisfied:

The position ①③ of the figure should be equipped with a lightning protection module. In general, it is recommended to install Type II in position ① and Type I in position ③.

B. When the safety and safety distance S is not met:

In addition to position 3, Type I lightning protection module should be installed in Figure ①②④.

3) The lightning down conductor and the equipment ground wire eventually sink at a total ground point, but the two cannot share the wire. That is, the equipment grounding wire should be pulled separately, and the wire diameter requirement $>6\text{mm}^2$ when the safety interval distance S is satisfied.

4) About the above lightning protection lightning receptor system related design reference GB/T 21714.3-2015.

Commissioning 7

7.1 Commission The Inverter



- If the inverter is stored over one month, its default time and date may look wrong, the time and date should be reset before connection to the grid.
- After the inverter installation is completed and before grid connection, the customer must select the correct country/region grid compliance standard in the settings. If no country/region standard is manually selected, the inverter will default to the VDE0126-1-1 standard after 30 seconds and operate accordingly.

7.1.1 Set inverter address

After inverter is started normally, inverter address can be set via RS485/USB converting to WIFI. When multiple inverters are connected in parallel via RS485, the inverter must be set to a different communication address. When a single inverter communicates, the default communication address can be used.

Note: The default communication address of the inverter is 1, which can be set to 1-254.

7.1.1.1 Set RS485 address with Shinebus

The 485 address of the inverter can be modified by Shinebus. This operation is performed by a professional.

7.1.1.2 Set RS485 address on ShinePhone APP

Refer to 8.2 download mobile APP ShinePhone and connect to inverter WIFI to enter local monitoring page, this operation is performed by a professional.

1>Click "Parameters";

2>Enter password. (When you use it for the first time, you need to set the password first. Click "Reset password" to enter the OSS account number and password. The distributor and installer can apply for the OSS account from Growatt. Click "Sign in" to set the password. After the setting is successful, you can start using it.)

3>Click top item "COM Address";

4>Click the "Read" button in the upper right corner to read the current communication address of the inverter;

5> Set inverter com address;

6>Read inverter com address to ensure setting is successful;




Fig 7.1

7.1.2 Set inverter time and date

Method 1:
Please refer to section 8.2.1 and login ShinePhone APP.Click "system time(45-50)" to set inverter time and date on the parameter setting page.




Fig 7.2

7.2 Operation Mode

7.2.1 Waiting mode

When the DC voltage is more than 180Vdc, inverter will be powered on and enters the "waiting" state.
At this mode, inverter will check the system parameter. If the system is normal and PV voltage is more than 195Vdc, inverter will try to connect to the grid.

7.2.2 Working mode

At this mode, inverter work normally,and the Power or fault code indicator light shows the power delivered by the inverter to the grid.
When the DC voltage is more than 180Vdc,inverter converts the DC power generated by the PV modules into AC power and supplies them to the grid.
When the DC voltage is lower than 180Vdc, inverter will enter into "waiting" state and try to connect to the grid, at this status, inverter consume very small power to check the internal system status.
Note: only when the PV modules supply enough power(voltage>195Vdc) then the inverter will start automatically.

7.2.3 Fault mode

Inverter intelligent control system will continuously monitor and adjust system status. When there is a fault detected, LED will show the fault message.

Note: Please refer to section 8.2 to check the fault message and take corrective measures.

7.2.4 Off mode

When the sunlight is weak or no light, inverter will stop working automatically. When it is off, inverter will not consume grid power or PV module. At the same time, the LED of inverter will be turned off.

Note: When PV string DC voltage is too low($\leq 150\text{Vdc}$), inverter will be off.

7.3 LED Display

Inverter current operation status can be visually checked from LED display directly.




Fig 7.3




Fig 7.4

Description of LED status			
Position of LED	Type of LED	Inverter status	LED status
A	PV voltage indicator light	PV voltage reaches grid voltage	Green light is on
		PV voltage does not reach the grid voltage	Light is not on
B	AC voltage indicator light	Inverter is in the grid state	Green light is on
		No AC voltage	Light is not on
		With AC voltage, inverter is in the grid countdown state	The green light flashes slowly, and the alarm or fault indicator light is not on

Description of LED status			
Position of LED	Type of LED	Inverter status	LED status
B	AC voltage indicator light	With AC voltage, inverter is in a fault state	The green light flashes slowly, and the alarm or fault indicator light is steady red.
C	Alarm or fault indicator light	Inverter works normally	Light is not on
		Inverter is in alarm state	Red light flashes slowly
		Inverter is in fault state	Red light is on
D	Communication indicator light	Inverter has external communication, such as RS485, GPRS, etc.	Green light is on
		Inverter has no external communication	Light is not on
		Inverter upgrade or USB interface is reading and writing data	Green light flashes
E	Power or fault code indicator light	Inverter is in the grid state	The eight LEDs from left to right represent the power of the inverter: if 8 green lights are on, it represents 100% of the inverter power. As shown in Figure 7.3, it represents 37.5% of the inverter power, and so on.
		Inverter is in fault state	The 8 LED lights from right to left represent the fault codes currently reported by the inverter. From right to left, they represent 1, 2, 4, 8, 16, 32, 64, and 128. For example, the first and fourth green LEDs on the right are always on, which means $1+8=9$. In addition, add 200 to get 209, which means the inverter reports fault 209, and so on.

8 Monitoring

8.1 Remote Data Monitoring

MAX-X2 series inverter remote monitoring ways include APP(ShinePhone) and server Web page, RS485,GPRS,4G,PLC(reserved) can satisfy both ways of monitoring.

8.1.1 Mobile phone APP(ShinePhone) remote monitoring

1>Scan the following QR code, or download from Android store or App store by searching "Shinephone", download and install software.



Fig 8.1

- Note:** 1.Make you it's the latest version.
2.Please find more details on <http://server.growatt.com>.

2>Users can register their mobile APP account by following the steps below:
Run ShinePhone, go to login page, click "register".Registration is required to fill in the information, with the * is required, the agreement is mandatory, you can log in to the main interface of ShinePhone after registration, the registration page and the main interface are as shown below.

Shinephone login and main page:




Fig 8.2



Fig 8.3

Device page:

- 1>Main page top middle is the name of current plant, user can click the " " button to switch to other plants under this account.
- 2>User can add datalogger,check datalogger and add plant by click "+" button at the top right corner.
- 3>Top half shows current plant power, revenue today and total production.
- 4>My device list shows current plant device, user can see more details by click the device, left cross the device to stick the device and edit, edit operation includes change device alias, icon,and delete device.




Fig 8.4 add datalogger




Fig 8.5 datalogger list




Fig 8.6 add plant

Datalogger:

- 1>User can add more datalogger under the particular plant.
- Way: Click "+" in the upper right corner of the device page and select "Add Collector (WiFi/GPRS, etc.)", as shown in Figure 8.7.
- Note: You can choose to manually enter the collector serial number for addition, or you can add it by scanning the barcode on the nameplate.




Fig 8.7

- 2>User can add datalogger at the datalogger list page to add a datalogger, edit, delete, configure etc.
- 3>User can add more plants with the add Plant function.

Device page and function:

- 1>Device page: User can click the device to see more details, the device page show current power and Energy today and daily power chart, user can find more with control,parameter, data and Events page.
- 2>Control: user set inverter on/off, set active power, set reactive power, set PF, set inverter time, set grid voltage high, set grid voltage low. The operation password is : inverter+date, for example inverter20170722.
- 3>Parameter: user can see device SN, rated power, firmware version, PV1 voltage, current, and power etc.




Fig 8.8




Fig 8.9



Fig 8.10

- 4>Data page: user can see the PV power, voltage, current, R phase power, S phase power, S phase power, T phase power, output power by day, month, year, by finger up cross the screen.
- 5>Events: User can see the fault message if there it is.




Fig 8.11

SASF803003	
SN:SASF803003	Type:Max
Even No.:125	Tag:PV input insulation i...
PV input insulation impedance too low	
2018-04-16 10:07:12.0	
SN:SASF803003	Type:Max
Even No.:125	Tag:PV input insulation i...
PV input insulation impedance too low	
2018-04-16 10:00:55.0	
SN:SASF803003	Type:Max
Even No.:125	Tag:PV input insulation i...
PV input insulation impedance too low	
2018-04-16 09:57:36.0	
SN:SASF803003	Type:Max
Even No.:125	Tag:PV input insulation i...
PV input insulation impedance too low	

Fig 8.12

8.1.2 GPRS /4G

8.1.2.1 Register account

1>Register account

Open browser, input "server.growatt.com", click "New User" at login page, input the necessary information then go back to login page, input the registered username and password, click "Sign In".



Fig 8.13

Register

Country *

Username *

Password *

Password confirm *

Language English ▼ *

E-Mail *

Installer code Enter the installer code or

☐ Agree with the Company's terms

Register
Back to login

Fig 8.14

2>Add datalogger

At Plant page, click device manage, then click add datalogger, input the SN and valid code then save, after device is powered on, datalogger will show after 5mins, also the device will come online(our device is monitored by datalogger, so need to add the datalogger here first).

Welcome : MAXtest (Normal user) [Exit](#)

MAX
▾
Dashboa
Plant
User Cen
Setting
Downloa
English
🔥

Plant data
device list
event list
Plant Detail

datalog
inverter
storage
hybrid inverter
Pcs
MAX
Hps
more

No.	SN	alias	device type	user name	connect status	
1	79Z0000024	79Z0000024	ShineGPRS	MAXtest	connection	/192.
2	79Z0000015	79Z0000015	ShineGPRS	MAXtest	connection	/192.
3	WLC082102D	WLC082102D	ShineGPRS	MAXtest	connection	/192.
4	79Z0000020	79Z0000020	ShineGPRS	MAXtest	connection	/192.168
5	79Z0000008	79Z0000008	ShineGPRS	MAXtest	connection	/192.168
6	79Z0000033	79Z0000033	ShineGPRS	MAXtest	connection	/192
7	79Z0000023	79Z0000023	ShineGPRS	MAXtest	connection	/192.
8	79Z0000014	79Z0000014	ShineGPRS	MAXtest	connection	/192.
9	WLC0821017	WLC0821017	ShineGPRS	MAXtest	lost	/192.
10	79Z0000021	79Z0000021	ShineGPRS	MAXtest	lost	/192.

add Enter the serial n search

previous
current
No. 1 page / total 5 page
next
1
Go

Fig 8.15

add data logger

SN *

belongs *

cancel save

Fig 8.16

No.	SN	alias	datalog	location	connect status	last login/update time	operating
1	SASF803004	SASF803004	79Z0000024	1	normal	2018-05-28 17:04:31	

Fig 8.17

No.	SN	alias	datalog	location	connect status	last login/update time	operating
1	SASF803004	SASF803004	79Z0000024	1	normal	2018-05-28 17:04:31	

Fig 8.18

3> Data reading

A. Basic production reading, Energy today, total production, revenue today and accumulative revenue are showing on this page.




Fig 8.19

B. Plant data page can check device power, voltage curve by time, day, month or year.




Fig 8.20

4>Set up the equipment

The device management page selects MAX. The serial number of the device to be set can be found in the list.

Notice: The following operations are requested by professionals.




Fig 8.21




Fig 8.22

5>Check detailed data

Double-click the device serial number in the device list. The detailed data page is displayed. Data pages can be viewed by date or exported.




Fig 8.23

History Data

start date2018-05-2end date2018-05-2searchexport


No.	Serial number	Time	Status	EacToday(kWh)	EacTotal(kWh)	Vpv1(V)	Vpv2(V)
1	SASF803004	2018-05-28 17:22:30	Normal	235.6	1341.0	542.6	609.0
2	SASF803004	2018-05-28 17:22:23	Normal	235.6	1341.0	543.4	611.9
3	SASF803004	2018-05-28 17:22:16	Normal	235.6	1341.0	552.7	612.8
4	SASF803004	2018-05-28 17:22:10	Normal	235.6	1341.0	549.4	617.2
5	SASF803004	2018-05-28 17:22:05	Normal	235.6	1341.0	541.8	619.9
6	SASF803004	2018-05-28 17:21:59	Normal	235.6	1341.0	543.6	619.2
7	SASF803004	2018-05-28 17:21:53	Normal	235.6	1341.0	542.5	622.5
8	SASF803004	2018-05-28 17:21:48	Normal	235.6	1341.0	537.0	615.8
9	SASF803004	2018-05-28 17:21:40	Normal	235.6	1341.0	537.1	619.2
10	SASF803004	2018-05-28 17:21:35	Normal	235.6	1341.0	540.3	624.9
11	SASF803004	2018-05-28 17:21:29	Normal	235.5	1340.9	549.9	618.2
12	SASF803004	2018-05-28 17:21:26	Normal	235.5	1340.9	544.2	608.8
13	SASF803004	2018-05-28 17:21:17	Normal	235.5	1340.9	543.9	618.6
14	SASF803004	2018-05-28 17:21:09	Normal	235.5	1340.9	543.3	614.4
15	SASF803004	2018-05-28 17:21:05	Normal	235.5	1340.9	545.9	616.5
16	SASF803004	2018-05-28 17:21:00	Normal	235.5	1340.9	544.9	617.6
17	SASF803004	2018-05-28 17:20:55	Normal	235.5	1340.9	549.1	619.0

close

Fig 8.24

8.1.2.2 Shinemaster monitoring

This is a cost-effective and compact monitoring device that is specially designed for solar power plants, with a high-speed CPU and a stable Linux system that intelligently records the user's system characteristics.




Feature :

- 1> A versatile and high-performance communication data logger that notifies the user of system status at any time.
- 2> Flexible parameter setting, system information management, error prompting and recording, high-capacity storage.
- 3> Collect data and upload data to Growatt in real time over the network.

Note: The smart meter and environmental monitor must be Growatt's designated manufacturer, otherwise monitoring will not be possible. When RS485 of multiple machines is used in parallel, please connect the ground wire according to section 6.3.1.

The system framework of communication monitoring is shown in the figure below. Users can choose the most suitable monitoring method according to the actual situation.



1>ShineMaster IP Address query

A.The PC and shinemaster lan ports are connected to the router's port through the network cable, so that they are in the same local area network.

B. Go to the router's management page and check the "Internet host list" to query the IP address of the ShineMaster serial number as the name of the connected device. This IP is the IP address assigned by the router to the ShineMaster. If you do not know how to do this, contact your network administrator for operation.

Note: The router needs to enable automatic IP assignment, that is, open the DHCP function.

C. Enter the shinemaster IP address in the browser to enter the shinemaster built-in page.

2>ShineMaster Built-in page access

Before accessing, check whether the communication cable between the devices is securely connected. After the check is correct, you can enter the ShineMaster IP address in the IE browser to access the built-in page of the ShineMaster. As long as the ShineMaster is on the same network segment as the computer you are accessing, you can access the ShineMaster built-in server.

A.If the user successfully visits the shinemaster built-in page, they can go directly to the built-in page login interface, as shown in figure 8.25 below.




Fig 8.25

B. Enter user name and password, default login username: admin password: admin. click login after filling in, enter growatt shinemaster system page.

3>ShineMaster Data collector status view

Click on the status of the shinemaster data collector to view shinemaster "system state information", "serial number," server address, "number of connected devices," and so on.

Growatt ShineMaster Setting Center
English

- [Datalogger State](#)
- [Datalogger Setting](#)
- [Network Setting](#)
- [System Management](#)
- [Device State](#)
- [Logout](#)

Datalogger Information	
State Info.	Online
SN	AEACESGI21
Server IP	server-cn.growatt.com
Server PORT	5279
Datalogger Location IP	192.168.0.6
Time	5
Datalogger MAC	00:47:15:6C:93:AB
Hardware Version	V1.0
Firmware Version	1.0.0.1
Datalogger Type	ShineMaster
Device Number	1
Offline Data Number	0
Location Time	2018-05-29 15:01:35
Anti-reflux Enable	DISABLE
Anti-reflux Power(W)	0

Fig 8.26

4>ShineMaster Data collector add or delete device

ShineMaster Before monitoring photovoltaic devices, we need to enter the page of the built-in shinemaster data collector settings to add devices.

A. Add device

1)Select the monitoring mode for monitoring photovoltaic devices in the first drop-down list of add or remove devices.

Growatt ShineMaster Setting Center
English

- [Datalogger State](#)
- [Datalogger Setting](#)
- [Network Setting](#)
- [System Management](#)
- [Device State](#)
- [Logout](#)

Datalogger Setting	
Net Mode	LAN
Anti-Reflux	☐ ON ☒ OFF
Select Anti-Reflux flow meter	(Input Meter Addr or SN)
Reflux Power(W)	(XX to Grid, -XX to User)
AntiRefluxChannel	NULL
Datalogger Time(YYYYMM-DD HH:MM:SS)	2018-05-29 17:42:40 Get Local Time
Reboot Able	☐ Yes ☒ No
Add or remove devices	RS485_1 NULL ☐ Add ☐ Del
Set BaudRate	NULL ☒ RS485_2 INVERTER SDM120 SDM630 BatteryBox
Save	

Fig 8.27

2)Select the type of photovoltaic device monitored in the second drop-down list.




Fig 8.28

3)Fill in the third drop-down list with the photovoltaic device correspondence address.




Fig 8.29

4)Select "Add" and then click "Save".

5)Go to the device status page after saving success to confirm that the device was added successfully.




Fig 8.30

B. Delete device

- 1) Select the first drop-down list of "add or remove devices" to monitor the monitoring mode of photovoltaic devices.
- 2) Select the type of photovoltaic device monitored in the second drop-down list.
- 3) Fill in the third drop-down list with the photovoltaic device correspondence address..
- 4) Select the following "del" and click Save to complete the device addition.
- 5) Enter the device status page after successful save to confirm that the device was deleted successfully.

5>ShineMaster Data upload to ShineServer

A. Register:Login

- 1) Enter the server domain name in the computer browser to enter the shinesserver login page, if you are logged in for the first time, please register the user name. Enter the domain name access page, as shown in figure 8.32 below.

Chinese user server domain name:<http://server-cn.growatt.com>.

The domain name of the international user server is:<http://server.growatt.com>.




Fig 8.31

- 2) Register user name, input user information according to prompt, after information is completed, click "register".

Note: "collector serial number" and "collector check code" see shinemaster serialNumber box or guarantee box.

Register

Country *

Username *

Password *

Password confirm *

Language *

E-Mail *

Installer code *

☐ Agree with the Company's terms

Register **Back to login**

Fig 8.32

B. View monitoring data

1) After registration is complete, jump to the shinesserver main interface automatically. Click on "power station" and "work information" to display the information for the power station's total power flow chart on the same day. The drop-down list "Select collector" allows you to view the daily power flow chart of a single inverter for the power station.




Fig 8.33

2) By clicking on "power station" and "equipment management" in turn, the real-time data of "data collector", "inverter", "environment monitor", "intelligent meter" and "confluence box" MAX " can be viewed.

8.2 Local Data Monitoring

MAX-X2 series Inverter local data monitoring mode has a mobile phone app phone) and PC direct connection, udisk, details are as follows.

8.2.1 Mobile phone app (Shinephone) Local Monitoring

8.2.1.1 Log on to app for local monitoring

Method 1

When you open the app login front page, click the top right corner toolbox icon. Pop up the toolbox, click the local debugging tool, and you can get the wifi name of the collector by scanning the QR code or barcode(The default password for WIFI is 12345678. If you have already connected, you can click "Skip" to connect directly to the WIFI.)




Fig 8.34

Method 2

Open app enter user name and password click login, enter me (personal center). Click the enter tool, find the local debugger to enter, and you can get the wifi name of the collector by scanning the QR code or barcode (The default password for WIFI is 12345678. If you have already connected, you can click "Skip" to connect directly to the WIFI.)




Fig 8.35

8.2.1.2 Use of local monitoring and debugging

When viewing local monitoring, you must keep the phone's wifi connected to the collector's wifi to view local monitoring (to enter the local monitoring page, first click auto refresh to get the latest data information).

Electricity generation: the option to view the latest generation, daily generation, monthly and annual generation of detailed information;

Power: you can see the current power and rated power value; failure: can read the equipment detailed fault information.

1>device control

Note: In addition to resetting the password to connect to the network, other WIFI modules that must connect to the collector can view information.

A.Reset password

Need network connection login oss account to set up or modify the local debug password.

B.Setting configuration

The configuration data of inverter, voltage, power and so on can be modified according to the usage (Fig 8.36).




Fig 8.36

C.Parameter configuration

The parameter data of the equipment can be modified according to the usage (Fig 8.37).

D.Intelligent detection

Detailed and accurate view of the device's detailed data and status (Fig 8.38).




Fig 8.37




Fig 8.38

E.Intelligent I-V curve scanning
Can remotely scan each mppt (Fig 8.39).




Fig 8.39

F.Fault recording detection
Remote, fast and accurate fault location (Fig 8.40).




Fig 8.40

G.Real-time recording detection
Inverter voltage and current quality can be observed in real time (Fig 8.41).




Fig 8.41

H. One click diagnosis

I-V curve diagnosis, grid waveform, THDV and cable impedance detection all at one click(Fig 8.42).

I. High level setting

According to the register address set parameters (professionals).

J. Device information

Check PV voltage/current, string voltage/current, AC voltage/current/power/frequency, PID voltage/current, internal parameters and device detail information and parameters (Fig 8.43).




Fig 8.42




Fig 8.43

8.2.2 U Disk Monitoring

Refer to 6.3.2 USB to WIFI/ U disk communicate connection, the local monitoring of U disk can realize the functions of software burning, fault recording, curve analysis and realtime recording. Details are as follows:

1>Firmware Programming

Create the bconfig.txt file under the root of the U disk, write to the following content, then insert the U disk to programming. Note the M3 program needs to be programming at last time.




Fig 8.44

2>Fault Recording

Create the bconfig.txt file under the root of the U disk, write the following content, then insert the U disk that can be read fault information, then generates a form under the files in the root directory, A total of 60 fault recording information is stored, the latest Numbers is 0.




Fig 8.45

3>Curve Analysis

Create the bconfig.txt file under the root of the U disk, write the following content, the insert U disk to record I-V curve, then generates a form under the files in the root directory.




Fig 8.46

4>Real Time Recording

Create the bconfig.txt file under the root of the U disk, write the following content, then insert U disk to read real time recording information, then generates a form under the files in the root directory, the form record's waveform is consistent with the ID of the command setting.




Fig 8.47

9 System Maintenance

9.1 Routine Maintenance

9.1.1 Cleaning Inverter

 DANGER	• Before any operation, please disconnect the DC switch and AC switch, and wait for at least 5 minutes until internal capacitance discharge completely.
---	---

- 1>Check the ambient temperature and dust of the inverter, clean the inverter when necessary.
- 2>Observe whether the air outlets is normal, when necessary, clean the air outlets or clean the fan step by step, steps refer to 9.1.2.
- 3>Check for dust accumulation or blockage in air vents and heat sinks. Clean if necessary.

Inspection Items	Inspection Methods	Maintenance Cycle
Equipment Cleaning	Check for dust accumulation or blockage in air vents and heat sinks. Clean if necessary.	1Once every 6-12 months (adjust to 3-6 months in dusty/fibrous environments).
Fan	Check for abnormal noise during fan operation. Inspect fan structure for cracks. Replace if necessary. Check for dust accumulation or blockage. Clean if needed.	1 time/year
Clear Vegetation Around Inverter	Remove weeds and perform cleaning based on local vegetation growth/withering. Prevent weed accumulation around inverter.	Adjust frequency based on vegetation growth around inverter.

9.1.2 Fan Maintenance

 DANGER	•It must be carried out by qualified, trained personnel and comply with all prevailing local code and regulations. •Please disconnect the DC switch and AC switch before any operation, and wait for at least 5 minutes until the internal bus capacitance discharge completely.
 WARNING	•Do not use the air pump cleaning fan, which may cause fan damage.

When the Growatt MAX-X2 series inverter work in high temperature environment, good ventilation and heat dissipation can effectively reduce the chance of load derating. Inverter equipped with internal cooling fans, when the internal temperature is too high, the fans work in to reduce the internal temperature. When the inverter is derating because of the internal temperature is too high, the following are the possible reasons or solutions.

- 1) Fan is blocked or the heat sink gathers too much dust, it needs to clean the fan, fan cover or heat sink.
- 2) Fan is damaged, it need to replace the fan.
- 3) Poor ventilation of the installation location, it needs to select the appropriate installation location according to the basic installation requirements.

Dust Filter and Fan Cleaning/Replacement Steps:

1>Before cleaning or replacing the dust filter/fan, ensure the inverter is completely disconnected from both DC and AC power sources.

- 1) Turn off DC switch.
- 2) Disconnect DC terminals from inverter(Users need tools to disconnect the DC connection terminals).
- 3) Turn off AC switch.

2>Replacing the Dust Filter.

1) Use a Phillips screwdriver to remove the screws securing the fan mounting plate (see diagram below).




Fig 9.1 Replace Dust Filter 1

2) Slide out the dust filter, then use a Phillips screwdriver to remove its mounting screws (see diagram below).




Fig 9.2 Replace Dust Filter 2

3) Remove the top dust filter using a Phillips screwdriver (see diagram below).




Fig 9.3 Replace the top Dust Filter

3>Replacing the Fan.

1) Use a Phillips screwdriver to remove the screws securing the fan mounting plate (see diagram below).




Fig 9.4 Replace the fan 1

2) Disconnect the fan connector, then unscrew the internal mounting screws of the fan bracket. Finally, remove the fan (see diagram below).




Fig 9.5 Replace the fan 2




Fig 9.6 External fan view




Fig 9.7 Internal fan view

Notice:(MAX-X2 series inverter has seven fans(internal fan*2Pcs)external fan*5Pcs).

4>Clean fan, fan guards and heat sink or replace fan.

- 1) Clean the fan and fan guards with air pump, brush or a damp cloth.
- 2) Remove each fan separately for cleaning if necessary.
- 3) Remove the fan that need to replace with a cross screwdriver, replace a new fan.
- 4) Tidy up the wire.

5>Install the fan, fan guard fixed and the inverter again.

9.2 Trouble Shooting



DANGER

- It must be operated by well-trained professional electrical technicians and abide by this manual.
- Normally grounded conductors may be ungrounded and energized when a PV isolation low is indicated.
- Risk of electric shock.

9.2.1 Warning

Warnings identify the current status of the inverter(Max), warnings do not related to a fault and it does not affect the normal running of the inverter. When a warning with a number after it appears in the display, it indicates a warning code and is usually cleared through an orderly shutdown/re-set or a self-corrective action performed by the inverter.

Warning	Description	Suggestion
Warning 200	String Fault	1.After shutdown,check the panel is normal. 2.Contact Growatt.
Warning 201	String abnormal	1.After shutdown,check the panel is normal. 2.Contact Growatt.
Warning 202	DC SPD warning	1.After shutdown,check the DC SPD. 2.Contact Growatt.
Warning 203	PV Circuit short	1.Check if the PV circuit is short-circuited. 2.Contact Growatt.
Warning 204	Dryconnect function abnormal	1.After shutdown,check the dry Dryconnect wiring. 2.Contact Growatt.
Warning 205	PV Boost driver abnormal	1.Restart inverter. 2.Contact Growatt.
Warning 206	AC SPD warning	1.After shutdown,check the AC SPD. 2.Contact Growatt.
Warning 207	USB Over-Current	1.unplug the U disk. 2.Re-access U disk after shutdown. 3.Contact Growatt.
Warning 208	DC Fuse Open	1.After shutdown,check fuse. 2.Contact Growatt.
Warning 209	PV Voltage High	1.Immediately disconnect the DC switch and check the voltage. 2.Contact Growatt.
Warning 210	PV Reversed	1.Check PV input terminals. 2.Contact Growatt.
Warning 219	PID function abnormal	1.Restart inverter. 2.If error message still exists,contact manufacturer.
Warning 220	Sting Disconnect	1.Check string Connect is normal. 2.If error message still exists,contact manufacturer.
Warning 221	Sting Current Unbalance	1.Check Pv panel is normal. 2.If error message still exists,contact manufacturer.

Warning	Description	Suggestion
Warning 222	DC switch abnormality	1. Please check whether the positive and negative poles of the string are reversed. If there is a reverse connection, please adjust the polarity of the string. If it still exists, contact Growatt. 2. If the DC switch is disconnected during operation, do not close it and contact Growatt. 3. If there are obvious abnormalities of the equipment, disconnect the AC/DC switch, wait for the photovoltaic string current to drop below 0.01A, and remove the DC terminal,contact Growatt.
Warning 303	Output overload	1.Reduce the output power. 2.Contact Growatt.
Warning 304	CT open circuit	1.Check CT wiring. 2.Contact Growatt.
Warning 305	CT is reversed	1.Check if the CT wiring is reversed. 2.Contact Growatt.
Warning 306	CT communication failed	1.Check CT communcation wiring. 2.Contact Growatt.
Warning 307	Wireless CT pairing timed out	1.Check communcation wiring. 2.Contact Growatt.
Warning 308	Meter open circuit	1.Check meter wiring. 2.Contact Growatt.
Warning 309	The meter reversed	1.Check if the meter wiring is reversed. 2.Contact Growatt.
Warning 310	Ground zero detection abnormal	1.After shutdown, Check whether the ground wire is connected well. 2.Contact Growatt.
Warning 400	Fan function abnormal	1.After shutdown,Check the fan connection. 2.Replace the fan. 3.Contact Growatt.
Warning 401	Meter abnormal	1.Check if the communication between the inverter and the meter is abnormal. 2.Check if the meter is on.
Warning 402	The communication between the optimizer and the inverter is abnormal	1.Check if the optimizer is turned on. 2.Check the connection between the optimizer and the inverter.

Warning	Description	Suggestion
Warning 403	String abnormal	1.After shutdown,check the panel is normal. 2.Contact Growatt.
Warning 404	EEPROM abnormal	1.Restart inverter. 2.Contact Growatt.
Warning 405	Firmware version abnormal	1.Restart inverter. 2.Contact Growatt.
Warning 406	Boost module error	1.Restart inverter. 2.Contact Growatt.
Warning 407	Over Temperature	1.Restart inverter. 2.Contact Growatt.
Warning 408	NTC broken	1.Restart inverter. 2.Contact Growatt.
Warning 409	Reactive abnormal	1.Check if shinemaster is abnormal. 2.Contact Growatt.
Warning 410	CPU Run abnormal	1.Restart inverter. 2.If error message still exists, contact manufacturer.
Warning 411	synchronization signal Abnormal	1.Check the synchronizing signal is abnormal. 2.If error message still exists, contact manufacturer.
Warning 412	The grid-connected startup condition of the inverter is not met	1.Check whether the grid voltage is out of range or whether the grid-connected voltage setting of the inverter is correct. 2.Check whether the PV voltage is too high or too low. 3.Restart the inverter. If error message still exists, contact manufacturer.

Notice: MAX series inverter has two external fans and five Internal fan.
If the suggestions do not work, please contact to Growatt.

9.2.2 Error

Errors codes identify a possible equipment failure, fault or incorrect inverter setting or configuration, any or all attempts to correct or clear a fault must be performed by qualified personnel.

Typically, the error code can be cleared once the cause or fault is removed.

Some of error code as table shows below, may indicate a fatal error and require you to contact the supplier or Growatt for help.

Error	Description	Suggestion
Error 200	AFCI Fault	1.After shutdown,check the panel terminal. 2.Restart inverter. 3.Contact Growatt.
Error 201	Residual I High	1.Restart inverter. 2.Contact Growatt.
Error 202	PV Voltage High	1.Immediately disconnect the DC switch and check the voltage. 2.Contact Growatt.
Error 203	PV Isolation Low	1. After shutdown, check if the panel shell is reliably grounded. 2. Contact Growatt.
Error 204	PV Reversed	1.After shutdown, check PV input terminals. 2.Contact Growatt.
Error 300	AC V Outrange	1.Check grid voltage. 2.Contact Growatt.
Error 301	AC terminals reversed	1.Check AC terminals. 2.Contact Growatt.
Error 302	No AC Connection	1.After shutdown,check AC wiring. 2.Contact Growatt.
Error 303	NE abnormal	1.After shutdown,ensure that the ground wire is reliably connected. 2.Contact Growatt.
Error 304	AC F Outrange	1.Check the frequency is in the range of specification or not. 2.Contact Growatt.
Error 305	Output overload protected	1.Check output load,Reduce the output power. 2.Contact Growatt.
Error 306	CT is reversed	1.Check if the CT wiring is reversed. 2.Contact Growatt.
Error 307	CT communication failed	1.Check CT communication wiring. 2.Contact Growatt.
Error 308	Wireless CT pairing timed out	1.Pairing between machine and CT timed out. Re-pair. 2.Contact Growatt.

Error	Description	Suggestion
Error 309	Grid Frequency abnormal	1.Check grid frequency,and Restart. 2.Contact Growatt.
Error 310	Ground zero protected	1. Confirm whether there is an isolation transformer on the output side. 2.For PV- connect ground version,N and PE may be connect.
Error 311	Anti-backflow failure protection	1.If the error is reported and the machine will be restarted soon, it is a normal protective shutdown. 2.Check the CT wiring. 3.Contact Growatt.
Error 400	DC component offset abnormality	1.Restart inverter. 2.Contact Growatt.
Error 401	The DC component of the output voltage is too high	1.Restart inverter. 2.Contact Growatt.
Error 402	The DC component of the output current is too high	1.Restart inverter. 2.Contact Growatt.
Error 403	Output current imbalance	1.Restart inverter. 2.Contact Growatt.
Error 404	DC BUS voltage sampling abnormal	1.Restart inverter. 2.Contact Growatt.
Error 405	Relay abnormal	1.Restart inverter. 2.Contact Growatt.
Error 406	initialization mode abnormal	1.Restart inverter. 2.Contact Growatt.
Error 407	Auto-detection failed	1.Restart inverter. 2.Contact Growatt.
Error 408	NTC Temperature too high	1.Restart inverter. 2.Contact Growatt.
Error 409	Bus voltage abnormal	1.Check whether the PV module string connections are secure and intact, and whether each string voltage is normal. Also check if the AC line voltage, phase voltage, and neutral-to-ground voltage are within normal ranges. 2.If all the above checks are normal, disconnect both the PV and AC power supplies, and immediately contact the equipment manufacturer's after-sales service department.

Error	Description	Suggestion
Error 410	The voltage of the flying capacitor abnormal protection	1.Restart inverter. 2.Contact Growatt.
Error 411	Communication fault	1.Restart inverter. 2.Contact Growatt.
Error 412	Temperature sensor abnormal	1.Restart inverter. 2.Contact Growatt.
Error 413	IGBT drive fault	1.Restart inverter. 2.Contact Growatt.
Error 414	EEPROM fault	1.Check if shinemaster is abnormal. 2.Contact Growatt.
Error 415	Internal power test fail	1.Restart inverter. 2.Contact Growatt.
Error 416	Over current protected	1.Restart inverter. 2.Contact Growatt.
Error 417	System communication protocol mismatch	1.Restart inverter. 2.Contact Growatt.
Error 418	Firmware version abnormal	1.Restart inverter. 2.Contact Growatt.
Error 419	Firmware and hardware versions do not match	1.Check firmware version. 2.Contact Growatt.
Error 420	GFCI Module damage	1.Restart inverter. 2.Contact Growatt.
Error 421	CPLD abnormal	1.Restart inverter. 2.Contact Growatt.
Error 422	Sampling is inconsistent	1.Restart inverter. 2.Contact Growatt.
Error 423	AC PWM Bypass Protect	1.Restart inverter. 2.If error message still exists,contact manufacturer.
Error 424	INV current abnormal	1.Restart inverter. 2.If error message still exists,contact manufacturer.
Error 425	AFCI self-test fault	1.Restart inverter. 2.Contact Growatt.
Error 426	PV current abnormal	1.Restart inverter. 2.Contact Growatt.
Error 427	AC current abnormal	1.Restart inverter. 2.Contact Growatt.
Error 428	Boost Short Out	1.Contact Growatt.

Error	Description	Suggestion
Error 429	Bus voltage softstart fail	1.Restart inverter. 2.Contact Growatt.
Error 431	Monitoring chip BOOT verification failed	1.Restart inverter. 2.Contact Growatt.

9.3 DC Switch Reset/Close Operation

If you see alarms such as "String Reverse Connection", "String Reverse Current", or an internal inverter fault via the mobile APP interface or remote monitoring system, and the DC switch is in the "OFF" state, it can be determined that the inverter's DC switch has tripped automatically. In this case, fault troubleshooting needs to be performed according to the alarm handling recommendations. The DC switch can only be reset and closed for re-powering after the fault is resolved.

After the fault is resolved, please follow the steps below to re-power:

Step 1>Use the switch handle provided in the accessory bag to turn the inverter's "DC SWITCH" to the "ON" position. A click sound indicates the switch is fully closed.

Step 2>Observe the LED indicators. If the PV voltage indicator shows a steady green light and the AC voltage indicator shows a steady red light, close the AC switch between the inverter and the grid.

Step 3>Observe the LED indicators to check the inverter's operating status. If the inverter is operating normally, the alarm/fault indicator will not have a slow red flash and the power indicator will be steadily lit.



Fig 9.8 DC switch status




Fig 9.9 Diagram for DC switch reset

Precautions:

When a photovoltaic (PV) inverter experiences a fault that cannot be identified or resolved independently, a power-off operation must be carried out immediately to avoid safety risks or further equipment damage caused by improper operation.

Operation Requirements:

1>During the power-off procedure, both the PV switch (inverter DC input switch) and the AC switch (AC distribution switch) must be turned off simultaneously to ensure the inverter is completely de-energized.

2>After the power-off operation, promptly report the fault through the official after-sales service channels specified in the user manual, and wait for handling by qualified service personnel.

Safety Warnings:

1>Please wear appropriate insulated protective equipment during operation to avoid the risk of electric shock.

2>Failure to turn off both the PV and AC switches may result in the equipment remaining energized, leading to electric shock hazards or further expansion of the equipment fault.

10 Specification

Model Specifications	MAX 100KTL3-X2 LV	MAX 110KTL3-X2 LV	MAX 120KTL3-X2 LV	MAX 125KTL3-X2 LV
Input Data(DC)				
Max.recommended PV power(for module STC)	150kW	165kW	180kW	187.5kW
Max.DC voltage	1100V			
Start voltage	195V			
Nominal voltage	600V			
MPP voltage range	180V-1000V			
Full-load MPPT voltage range	550V-850V	550V-850V	600V-850V	600V-850V
No.of MPP trackers	8			
No.of PV strings per MPP trackers	2			
Max.input current per MPP trackers	45A			
Max.short-circuit current per MPP trackers	56.5A			
DC overvoltage category	Category II			
Output Data(AC)				
AC nominal power	100kW	110kW	120kW	125kW
Max.AC apparent power	110kVA	121kVA	132kVA	137.5kVA
Nominal AC voltage/range	220V/380V 230V/400V 340-440VAC			
AC grid frequency/range	50/60Hz 45-55Hz/55-65Hz			
Max.output current	167.1A@380V 158.8A@400V	183.8A@380V 174.6A@400V	200.5A@380V 190.5A@400V	208.9A@380V 198.5A@400V
Power factor (@nominal)	>0.99			
Max.inrush current/duration	20KA/tr:8us,tf:20us			
Max.output facult current/duration	400A/30us			
Adjustable power factor	0.8leading ...0.8lagging			

Model Specifications	MAX 100KTL3-X2 LV	MAX 110KTL3-X2 LV	MAX 120KTL3-X2 LV	MAX 125KTL3-X2 LV
THDi	<3%			
AC grid connection type	3W/N/PE			
AC overvoltage category	Category III			
Efficiency				
Max.efficiency	98.8%			
Euro-eta	98.4%	98.5%	98.5%	98.5%
Protection devices				
DC reverse-polarity protection	Yes			
DC switch	Yes			
DC Surge protection	Type II			
Insulation resistance monitoring	Yes			
AC surge protection	Yes			
Grid monitoring	Yes			
Anti-islanding protection	Yes			
Residual-current monitoring unit	Yes			
String monitoring	Yes			
Anti-PID function	Optional			
AFCI protection	Optional			
General data				
Dimensions (W /H / D) in mm	970*640*345mm			
Max. inrush current/duration	20KA/tr:8us,tf:20us			
Weight	84kg			
Operating temperature range	-30°C- +60°C			
Altitude	4000m			

Model Specifications	MAX 100KTL3-X2 LV	MAX 110KTL3-X2 LV	MAX 120KTL3-X2 LV	MAX 125KTL3-X2 LV
Internal consumption at	<1W(Note1)			
Topology	Transformerless			
Cooling	Smart air cooling			
Protection degree	Ip66			
Relative humidity	0~100%			
DC connection	H4/MC4(Optional)			
AC connection	OT/DT terminal			
Interfaces				
Display	LED/WIFI+APP			
RS485/USB	Yes			
PLC/GPRS/4G	Optional			
Warrant:5 /10 years	Optional			
Certificates and approvals				
Grid regulation	AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3			
EMC	EN61000-6-2,EN61000-6-4			
Safety	IEC/EN62109-1,IEC/EN62109-2			
Note1: If with AC power supply function, self-consumption at night is less than 15W.				

Model Specifications	MAX 133KTL3-X2 LV	MAX 125KTL3-X2 MV	MAX 136KTL3-X2 MV	MAX 150KTL3-X2 MV
Input Data(DC)				
Max.recommended PV power(for module STC)	199.5kW	187.5kW	204kW	225kW
Max.DC voltage	1100V			
Start voltage	195V			
Nominal voltage	600V	720V	720V	720V
MPP voltage range	180V-1000V			
Full-load MPPT voltage range	600V-850V	600V-850V	685V-850V	685V-850V
No.of MPP trackers	8			
No.of PV strings per MPP trackers	2			
Max.input current per MPP trackers	45A			
Max.short-circuit current per MPP trackers	56.5A			
DC overvoltage category	Category II			
Output Data(AC)				
AC nominal power	133kW	125kW	136kW	150kW
Max.AC apparent power	146.3kVA	137.5kVA	150kVA	165kVA
Nominal AC voltage/range	220V/380V 230V/400V 340-440VAC	277V/480V 408-528VAC	277V/480V 408-528VAC	277V/480V 408-528VAC
AC grid frequency/range	50/60Hz 45-55Hz/55-65Hz			
Max. output current	222.3A@380V 211.2A@400V	165.4A	179.9A	198.5A
Power factor(@nominal)	> 0.99			
Max.inrush current/duration	20KA/tr: 8us,tf:20us			
Max. output fault current/duration	400A/30us			
Adjustable power factor	0.8leading ...0.8lagging			

Model Specifications	MAX 133KTL3-X2 LV	MAX 125KTL3-X2 MV	MAX 136KTL3-X2 MV	MAX 150KTL3-X2 MV
THDi	<3%			
AC grid connection type	3W/N/PE	3W+PE	3W+PE	3W+PE
AC overvoltage category	Category III			
efficiency				
Max.efficiency	98.8%	99%	99%	99%
Euro-eta	98.5%			
Protection devices				
DC reverse-polarity protection	Yes			
DC switch	Yes			
DC Surge protection	Type II			
Insulation resistance monitoring	Yes			
AC surge protection	Yes			
Grid monitoring	Yes			
Anti-islanding protection	Yes			
Residual-current monitoring unit	Yes			
String monitoring	Yes			
Anti-PID function	Optional			
AFCI protection	Optional			
General data				
Dimensions (W / H / D) in mm	970*640*345mm			
Max. inrush current/duration	20KA/tr:8us,tf:20us			
Weight	84kg			
Operating temperature range	-30°C- +60°C			
Altitude	4000m			

Model Specifications	MAX 133KTL3-X2 LV	MAX 125KTL3-X2 MV	MAX 136KTL3-X2 MV	MAX 150KTL3-X2 MV
Internal consumption at	< 1W(Note1)			
Topology	Transformerless			
Cooling	Smart air cooling			
Protection degree	IP66			
Relative humidity	0~ 100%			
DC connection	H4/MC4(Optional)			
AC connection	OT/DT terminal			
Interfaces				
Display	LED/WIFI+APP			
RS485/USB	Yes			
PLC/GPRS/4G	Optional			
Warranty: 5 /10 years	Optional			
Certificates and approvals				
Grid regulation	AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3			
EMC	EN61000-6-2,EN61000-6-4			
Safety	IEC/EN62109-1,IEC/EN62109-2			
Note1: If with AC power supply function, self-consumption at night is less than 15W.				

Model Specifications	MAX 50KTL3-XL2	MAX 60KTL3-XL2	MAX 70KTL3-XL2	MAX 73KTL3-XL2
Input Data(DC)				
Max.recommended PV power(for module STC)	75kW	90kW	105kW	109.5kW
Max.DC voltage	800V			
Start voltage	195V			
Nominal voltage	370V			
MPP voltage range	180V-800V			
Full-load MPPT voltage range	360V-650V			
No.of MPP trackers	8			
No.of PV strings per MPP trackers	2			
Max.input current per MPP trackers	45A			
Max.short-circuit current per MPP trackers	56.5A			
DC overvoltage category	Category II			
Output Data(AC)				
AC nominal power	50kW	60kW	70kW	73kW
Max.AC apparent power	55kVA	66kVA	66kVA@208V 70kVA@220V 73kVA@230V	69kVA@208V 73kVA@220V 75kVA@230V
Nominal AC voltage/range	127V/220V 101.6-139.7VAC			
AC grid frequency/range	50/60Hz 45-55Hz/55-65Hz			
Max. output current	144.3A@220V	173.2A@220V	183.7A@220V	191.6A@220V
Power factor(@nominal)	>0.99			
Max.inrush current/duration	20KA/tr:8us,tf:20us			
Max.output fault current/duration	400A/30us			
Adjustable power factor	0.8leading ...0.8lagging			

Model Specifications	MAX 50KTL3-XL2	MAX 60KTL3-XL2	MAX 70KTL3-XL2	MAX 73KTL3-XL2
THDi	<3%			
AC grid connection type	3W/N/PE			
AC overvoltage category	Category III			
efficiency				
Max.efficiency	98.8%			
Euro-eta	98.3%			
Protection devices				
DC reverse-polarity protection	Yes			
DC switch	Yes			
DC Surge protection	Type II			
Insulation resistance monitoring	Yes			
AC surge protection	Yes			
Grid monitoring	Yes			
Anti-islanding protection	Yes			
Residual-current monitoring unit	Yes			
String monitoring	Yes			
Anti-PID function	Optional			
AFCI protection	Optional			
General data				
Dimensions (W /H / D) in mm	970*640*345mm			
Max.inrush current/duration	20KA/tr:8us,tf:20us			
Weight	84kg			
Operating temperature range	-30°C- +60°C			
Altitude	4000m			

Model Specifications	MAX 50KTL3-XL2	MAX 60KTL3-XL2	MAX 70KTL3-XL2	MAX 73KTL3-XL2
Internal consumption at	<1W(Note1)			
Topology	Transformerless			
Cooling	Smart air cooling			
Protection degree	IP66			
Relative humidity	0~100%			
DC connection	H4/MC4(Optional)			
AC connection	OT/DT terminal			
Interfaces				
Display	LED/WIFI+APP			
RS485/USB	Yes			
PLC/GPRS/4G	Optional			
Warranty:5 /10 years	Optional			
Certificates and approvals				
Grid regulation	AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3			
EMC	EN61000-6-2,EN61000-6-4			
Safety	IEC/EN62109-1,IEC/EN62109-2			
Note1: If with AC power supply function, self-consumption at night is less than 15W.				

Model	MAX 75KTL3-XL2
Specifications	
Input Data(DC)	
Max.recommended PV power(for module STC)	112.5kW
Max.DC voltage	800V
Start voltage	195V
Nominal voltage	370V
MPP voltage range	180V-800V
Full-load MPPT voltage range	360V-650V
No.of MPP trackers	8
No.of PV strings per MPP trackers	2
Max.input current per MPP trackers	45A
Max.short-circuit current per MPP trackers	56.5A
DC overvoltage category	Category II
Output Data(AC)	
AC nominal power	75kW
Max.AC apparent power	71kVA@208V/75kVA@220V/78.4kVA@230V
Nominal AC voltage/range	127V/220V 101.6-139.7VAC
AC grid frequency/range	50/60Hz 45-55Hz/55-65Hz
Max.output current	196.9A@220V
Power factor(@nominal)	>0.99
Max.inrush current/duration	20KA/tr:8us,tf:20us
Max.output fault current/duration	400A/30us
Adjustable power factor	0.8leading ...0.8lagging
THDi	<3%

Model	MAX 75KTL3-XL2
Specifications	
AC grid connection type	3W/N/PE
AC overvoltage category	Category III
efficiency	
Max. efficiency	98.8%
Euro-eta	98.3%
Protection devices	
DC reverse-polarity protection	Yes
DC switch	Yes
DC Surge protection	Type II
Insulation resistance monitoring	Yes
AC surge protection	Yes
Grid monitoring	Yes
Anti-islanding protection	Yes
Residual-current monitoring unit	Yes
String monitoring	Yes
Anti-PID function	Optional
AFCl protection	Optional
General data	
Dimensions (W / H / D) in mm	970*640*345mm
Max.inrush current/duration	20KA/tr:8us,tf:20us
Weight	84kg
Operating temperature range	-30°C- +60°C
Altitude	4000m

Model	MAX 75KTL3-XL2
Specifications	
Internal consumption at	< 1W(Note1)
Topology	Transformerless
Cooling	Smart air cooling
Protection degree	IP66
Relative humidity	0~100%
DC connection	H4/MC4(Optional)
AC connection	OT/DT terminal
Interfaces	
Display	LED/WIFI+APP
RS485/USB	Yes
PLC/GPRS/4G	Optional
Warranty:5 /10 years	Optional
Certificates and approvals	
Grid regulation	AS/NZS 4777.2,CEI 0-21,CEI 0-16,VDE-AR-N 4105, DIN V VDE V 0126-1-1,UTE C 15-712-1,EN 50438, IEC 60068,IEC 61683,IEC 62116,IEC 61727, MEA,PEA,DRRG/DEWA:2016,BDEW,G59/3
EMC	EN61000-6-2,EN61000-6-4
Safety	IEC/EN62109-1,IEC/EN62109-2
Note1: If with AC power supply function, self-consumption at night is less than 15W.	

11 Decommissioning

If the inverter does not operate in the future, it needs to be properly disposed. The steps are as follows:

- 1> Disconnect the external AC short circuit and prevent reconnection due to misoperation.
- 2> Turn the DC switch to "OFF" position.
- 3> Wait at least 5 minutes until the internal capacitor discharge is completed.
- 4> Disconnect the AC connector.
- 5> Disconnect DC connector.
- 6> Remove the inverter from the wall.
- 7> Disposing of the inverter.

11.1 Disposing Of The MAX-X2 Series Inverter

	Do not dispose of MAX series inverter together with household waste. Please accordance with the disposal regulations for electronic waste which apply at the installation site at that time. Ensure that the old unit and, where applicable, any accessories are disposed of in a proper manner.
---	---

12 Quality assurance

Please refer to related file.

Contact 13

If you have technical problems concerning our products, contact your installer or Growatt, please provide information below for better support.

1> Inverter type

2> Serial number of inverter

3> Error code of inverter

4> LED status of inverter

5> DC input voltage of inverter (Modules information)

6> Inverter communication method

Shenzhen Growatt New Energy CO., Ltd.

4-13/F, Building A, Sino-German (Europe) Industrial Park,
Hangcheng Blvd, Bao'an District, Shenzhen, China

E service@growatt.com

W en.growatt.com

For local customer support, please visit <https://en.growatt.com/support/contact>



Download
Manual



Growatt New Energy

Shenzhen Growatt New Energy CO., Ltd.

4-13/F, Building A, Sino-German (Europe) Industrial Park,
Hangcheng Blvd, Bao'an District, Shenzhen, China

E service@growatt.com

W en.growatt.com

For local customer support, please visit <https://en.growatt.com/support/contact>

GR-UM-260-A-05 (PN:044.0100105)